Los Angeles World Airports

Capital Programming, Planning and Engineering Group

Autodesk Civil 3D Standards and Practices

FINAL

Utility Infrastructure Project

Los Angeles International Airport (LAX)

Project Manager: Teresa Sarullo. P. E.

BY: HNTB

DATE: July 08, 2015



Autodesk Civil 3D Standards for LAWA Projects

Document History

Revision letter	Release date	Major changes	Approved by

Table of Contents

About this book
Relation to existing standards3
Who should read this book
How this book is organized4
Related documents
Abbreviations
Introduction6
Benefits of CAD Standards6
General principles6
Templates6
Standards in use at LAWA7
LAWA standards7
National and International standards8
Compliance8
Compliance
Request of Variance
Request of Variance 8 Autodesk Civil 3D 9
Request of Variance
Request of Variance 8 Autodesk Civil 3D 9 General Settings 9 Civil 3D labels 12
Request of Variance8Autodesk Civil 3D9General Settings9Civil 3D labels12Civil 3D Parts Lists13
Request of Variance8Autodesk Civil 3D9General Settings9Civil 3D labels12Civil 3D Parts Lists13Civil 3D Pipe Styles15
Request of Variance8Autodesk Civil 3D9General Settings9Civil 3D labels12Civil 3D Parts Lists13Civil 3D Pipe Styles15GIS Attribute Data20
Request of Variance8Autodesk Civil 3D9General Settings9Civil 3D labels12Civil 3D Parts Lists13Civil 3D Pipe Styles15GIS Attribute Data20Autodesk Civil 3D Property Sets21
Request of Variance8Autodesk Civil 3D9General Settings9Civil 3D labels12Civil 3D Parts Lists13Civil 3D Pipe Styles15GIS Attribute Data20Autodesk Civil 3D Property Sets21Sample Civil 3D views24

About this book

The standards described in this document are provided to help LAWA staff, consultants and project partners prepare CAD files for use in LAWA projects using Autodesk Civil 3D software. By using these standards, LAWA will achieve a standardized approach to spatial data management and related record document(s) that will bring many benefits to both the organization and its staff. These benefits include, but are not limited to:

- consistent and more reliable data that will lead to more informed decision making
- closer integration with other LAWA information systems and LAWA spatial data users
- portability of staff skills
- greater interoperability with organizations outside of LAWA

Relation to existing standards

These LAWA-specific Civil 3D standards are generally derived from LAWA CAD Standards and industry best practices when using the software.

Who should read this book

This book is intended for all LAWA project partners, and especially for members of their staff who prepare CAD drawings using Autodesk Civil 3D software for use within a project. It is provided to promote and support effective implementation of CAD drawing standards within the airport, for the full project life-cycle.

How this book is organized

After the introduction, this book contains the following chapters and appendixes:

Civil 3D General

Settings and general information regarding using Autodesk Civil 3D.

Civil 3D Pipe Networks

Descriptions of custom LAWA Pipe networks

GIS Data Workflows

Processes for dealing with LAWA required Object Data in Civil 3D

Related documents

BIM, GIS, Survey, Metadata and EDI standards along with other documentation related to these standards are available on the LAWA website on the LAWA Standard Documents and Guidelines page: <u>http://www.lawa.org/welcome_LAWA.aspx?id=542</u>

Abbreviations

- AEGIS Airport Enterprise Geographical Information System
- ANSI American National Standards Institute
- BIM Building Information Modeling
- CAD Computer Aided Design and Drafting
- CPPE Capital Planning, Programming and Engineering
- CSDGM Content Standard for Digital Geospatial Metadata
- DDMS Document & Drawing Management System
- EDI Electronic Data Interchange
- FAA Federal Aviation Administration
- FGDC The Federal Geographic Data Committee
- GIS Geographic Information System
- **GISSSD GIS Support Services Division**
- IMTG Information Management Technology Group
- ISO International Organization for Standardization
- LAWA Los Angeles World Airports
- LAX Los Angeles International Airport
- ONT Ontario Airport
- PMD Palmdale Airport
- SDSFIE Spatial Data Standards for Facilities, Infrastructure, and Environment
- VNY Van Nuys Airport

Introduction

This document establishes Standards and Procedures for Autodesk Civil3D submittals to Los Angeles World Airports (LAWA). These processes are necessary for efficient Electronic Data Exchange between the airport and consultants and to ensure the data received by LAWA is compliant with internal data standards

Benefits of CAD Standards

Drawing up and implementing detailed standards for CAD files standards is intended to ensure a smooth flow of information at every stage of the project. Consistent, comparable files bring benefits that include the following:

- project partners can share information confidently and easily
- common format and comparable detail references are used for all projects within LAWA
- information is presented in the same place in each set of drawing files
- non-compliance and other errors can be quickly detected, reducing the need for change requests
- data can easily be translated between languages and file-formats; document storage and retrieval can be automated

General principles

- except for some specialized schematics, the software used to produce CAD drawings is AutoCAD (a recent version)
- the unit of measurement used for CAD architectural drawings is the inch
- the unit of measurement used for CAD civil drawings is the U.S. foot
- project codes are defined by LAWA on a project per project basis
- all civil drawings must be created in NAD 83 California State Planes, Zone V, US Foot coordinate system
- all civil drawings will identify the survey epoch used, for example NSRS 2007, CORS 96, etc..
- all architectural drawings must use positive values for coordinates
- all spatial data must be created in "Model Space"
- all graphical elements must be in "Paper Space"

Templates

Project partners and subcontractors who need to implement the CAD standards for LAWA projects can download templates to provide a working environment based on the LAWA CAD Standards. Each template (.dwt file) defines the layers for a specific discipline. Sample title blocks can also be downloaded.

Standards in use at LAWA

LAWA standards

This section provides an overview of LAWA specific standards, plus related federal, local, and national standards. LAWA standards have been created to improve productivity and reliable information exchange through the full life-cycle of geospatial data, CAD and BIM files along with related documents.

LAWA Metadata Standards

Metadata is structured information that describes, explains, locates, or otherwise makes it easier to retrieve, use, or manage an information resource. Metadata is often called data about data or information about information.

LAWA GIS Standards

The LAWA GIS standards are directly based on the ANSI Spatial Data Standard for Facilities Infrastructure and Environment (SDSFIE), Release 2.60, extended in certain areas to handle specific information relevant to LAWA. GIS Standards for LAWA Projects presents the most important aspects of SDSFIE as it applies to LAWA.

LAWA Survey Standards

The LAWA Survey and Remote Sensing Standards are based on requirements laid out in Airport Circulars published by the FAA, adapted where necessary to suit LAWA-specific requirements.

LAWA BIM Standards

These guidelines focus primarily on adaptation of standards for practical and efficient application of BIM, particularly at the handover (Record - As-Built) stage of a project. Based on USACE_CAD-BIM_Technology Center: version 1.1 and National BIM standard (United States): version2

LAWA EDI (Electronic Data Interchange) Standards

This Standard provides a framework for all data requests and all hard copy or electronic data submittals to or from LAWA, thus ensuring a streamlined data exchange process

National and International standards

AIA CAD Layer Guidelines and the National CAD Standards (NCS)

The LAWA CAD standards are based largely on the AIA CAD Layer Guidelines and the National CAD Standards (NCS), adapted where necessary to suit LAWA-specific requirements.

SDSFIE 2.6

The overall structure of LAWA current geospatial repository is based on SDSFIE 2.6. SDSFIE organizes real world features such as runways, roads and water pipes into a hierarchical structure.

Compliance

Having timely up to date, accurate, fully compliant data available to the LAWA community forms an integral part of planning within any project. The aim of these standards is to ensure a smooth data transfer of information into the LAWA geospatial data base and efficient data maintenance through the complete data lifecycle. Accordingly, the terms and conditions of a LAWA contract require compliance with these standards.

Failure to comply with these standards may result in organizations being back-charged for any financial costs incurred by LAWA for rectifying inconsistencies and errors

The individual or organization submitting the files is also responsible for ensuring that all links between non-graphic data and graphic data, and all relationships between database tables, shall be preserved or automatically reconstructed when data is transferred to the LAWA GIS environment.

Request of Variance

Compliance with the LAWA standards and data deliverables demands are the cornerstone of achieving trustworthy and relevant data.

Suggestions for improvements or extensions to these standards and demands are encouraged, to meet unforeseen requirements and as a way to improve effectiveness and clarify any ambiguities; any such deviation must be approved by LAWA, in advance and in writing. . Requests need to be submitted on the "Request for variance" form, this form along with other documentation related to these standards are available on the LAWA website. http://www.lawa.org/welcome_LAWA.aspx?id=542

Autodesk Civil 3D

General Settings

Current version

The current LAWA approved version of Autodesk Civil 3d is **2014.** Use of a year release other than the currently approved version will require written approval from LAWA xxxx Department.

File Management

When delivering Civil 3D content to LAWA, use the built-in eTransmit function. This packages the document with all dependencies. From the Application menu (the button on the top left with C3D on it), select Publish, then eTransmit.



Object Data / Attribute Data

Layers

The LAWA Civil 3D template (.dwt) is prepopulated with LAWA compliant layers. Individual Pipe styles are set to use the compliant layer standards. If additional layers are required, please refer to the LAWA CAD Standards document for information regarding LAWA CAD layer standards.

Coordinate Systems

The LAWA Civil 3D template (.dwt) is preset with the current LAWA approved Coordinate System (CA83-VF). Modification of the Coordinate System should only be done at the direction of LAWA

To set the Coordinate system in Civil 3D, first switch the Workspace to Planning and Analysis. Then from the Map Setup tab on the Ribbon, select Assign in the Coordinate System panel.



Select CA83-VF from the list and Assign at the bottom of the dialog box

-	Assigned						
de:	-						
escriptio	on: -						
ow —							
atus: U	p to date	Code type: Autodesk	 Category: N 	lo filter selected	Unit: No filter sel	ected 🔻	
arch —							
alifornia	4						
Status	Code	Description	Definition type	Referenced to	Categories	EPSG code	Unit
0	CA83-I	NAD83 California State Planes, Zo	P	b NAD83	USA, California	26941	Meter
0	CA83-IF	NAD83 California State Planes, Zo	P	b NAD83	USA, California	2225	US Survey Foot
0	CA83-II	NAD83 California State Planes, Zo	P	b NAD83	USA, California	26942	Meter
0	CA83-IIF	NAD83 California State Planes, Zo	P	b NAD83	USA, California	2226	US Survey Foot
0	CA83-III	NAD83 California State Planes, Zo	P	b NAD83	USA, California	26943	Meter
0	CA83IIIF	NAD83 <mark>California</mark> State Planes, Zo	P	🖏 NAD83	USA, <mark>California</mark>	2227	US Survey Foot
0	CA83-IV	NAD83 California State Planes, Zo	P	🖏 NAD83	USA, <mark>California</mark>	26944	Meter
0	CA83-IVF	NAD83 California State Planes, Zo	P	🖏 NAD83	USA, <mark>California</mark>	2228	US Survey Foot
0	CA83-V	NAD83 California State Planes, Zo	P	🖏 NAD83	USA, <mark>California</mark>	26945	Meter
0	CA83-VF	NAD83 California State Planes, Zo	P	🖏 NAD83	USA, <mark>California</mark>	2229	US Survey Foot
0	CA83-VI	NAD83 California State Planes, Zo	P	b NAD83	USA, <mark>California</mark>	26946	Meter
0	CA83-VIF	NAD83 California State Planes, Zo	P	b NAD83	USA, <mark>California</mark>	2230	US Survey Foot
0	CAHP-I	California Zone I, Meter (or use H	P	🐌 HPGN	USA, <mark>California</mark>	2766	Meter
0	CAHP-IF	California Zone I, US FT (or use H	P	🖏 HPGN	USA, <mark>California</mark>	2870	US Survey Foot
0	CAHP-II	California Zone II, Meter (or use H	P	🖏 HPGN	USA, <mark>California</mark>	2767	Meter
0	CAHP-IIF	California Zone II, US FT (or use H	P	🐌 HPGN	USA, <mark>California</mark>	2871	US Survey Foot

Civil 3D labels

Lables can be added to Civil 3D Pipes and Structres using data such as Pipe Material, Pipe, Length, and Slope. Label Styles can be created in the Settings Tab of the Toolspace Panel. Label Styles shall be created using the appropriate LAWA standards, including font and layer information.



Once a Label Style has been created, use the Add Labels button (located on the Annotate Tab of the Civil 3D ribbon) to bring up the Add Labels Dialog Box. Select the desired Label Style, and then follow the prompts to attach a label to the correct Civil 3D element. Once a label is attached, it should look similar to the following:



Civil 3D Parts Lists

The appropriate parts list must be selected when building LAWA Civil 3D pipe networks. NOTE: Pipe Networks differ from Pressure Networks, and the available parts list will be dependent on which network is being built. Individual Parts are set to use the compliant Pipe Styles which are set to use the LAWA layer standards.

Pipe Networks

Using the Pipe Network Creation Tool, select the appropriate Network Parts List from the available drop down menu.

A Create Pipe Network	— ×
Network name:	
Network - (<[Next Counter(CP)]>)	R
Network description:	
Network parts list:	
Storm Sewer	· 🏹 🕶
Layers	
Surface name:	
<none></none>	
Alignment name:	
<none></none>	
Structure label style:	
<none> 🔻 🗾</none>	
Pipe label style:	
<none> 🔻 🊺</none>	
OK Cancel	Help

Pressure Networks

Using the Pressure Network Creation Tool, select the appropriate Parts List from the available drop down menu.

🔺 Create Pressure Pipe Network 🛛 💌
Network name:
Pressure Network - (<[Next Counter(CP)]>
Network description:
Parts List
Domestic Water 🗸 🔽
Layers
Surface name:
<none></none>
Alignment name:
<none></none>
Pressure Pipe Label Style:
<none> 🔹 🚺</none>
Fitting Label Style:
<none> 🔹 🚺</none>
Appurtenance Label Style:
<none> 🔻 🏹 🖸</none>
OK Cancel Help

Civil 3D Pipe Styles

New Pipe styles are created using the Pipe Style Editor dialog box. This can be accessed via the Settings Tab on a drawing's Toolspace.

	×	ति <u>,</u> स	?]
		Master View		- jā
		🖃 📄 LAWA Civil 3d Master Template 2014	-	Prospector
		🗄 🖑 🕅 General		۲, The second s
		🗄 🗇 Point		
		🗄 🐵 Point Cloud		
		🗄 🌧 Surface		
		🗄 🖏 Parcel		S S
		🗄 🕥 Grading		Settings
		🗄 🗁 Alignment		S
		🗄 Mrofile		
		🗄 🔝 Profile View		
		🖶 🕋 Superelevation View		
		🗄 🔝 Cant View		<u>ه</u>
		🗄 🗁 Sample Line		Survey
		🗄 🛧 Section		
		🗄 🍈 Section View		
		🖶 🚭 Mass Haul Line		
		🗄 🤷 Mass Haul View		
		🗄 📴 Catchment		ŏ
e.		🖶 🎢 Pipe Network	Ξ	Toolbox
nag		🖶 🥟 Pipe		IIF.
Sheet Set Manager		Pipe Styles New		
Set		🕀 🗁 Pipe Rule Set		
leet		E Dabel Styles		
ι Σ		🗄 🗁 Table Styles		
		🗄 🛱 Structure		
		📩 🎹 Droccuro Motwork		

During the style creation process, the new Pipe Style should be properly assigned to LAWA's standard layers.

Pipe Style - Sanitary (Sin	gle Line)						
formation Plan Profile	Section Display	Summary					
View Direction:	ŕ	1					
Plan	•						
Component display:							
Component Type	Visible	Layer		Color	Linetype	LT Scale	Linewei.
Pipe Centerline	2	C-SSWR-CNTR			ByLayer	1.0000	ByLayer
Inside Pipe Walls		C-SSWR-PIPE			ByLayer	1.0000	ByLayer
Outside Pipe Walls	ÿ	C-SSWR-PIPE			ByLayer	1.0000	ByLayer
Pipe End Line	ÿ	C-SSWR-PIPE			ByLayer	1.0000	ByLayer
Pipe Hatch	ý	C-SSWR-PIPE-PAT	т		ByLayer	1.0000	ByLayer
Pipe Solid		C-SSWR-PIPE			ByLayer	1.0000	ByLayer
 Component hatch display: 							•
Component Type	Pattern	A	ngle		Scale		
Pipe Hatch	∭user single	45			1.0000		
			ОК	Cancel	A	pply	Help

The Civil 3D Pipe Styles are automatically selected based on the Parts List being used. However, if the Pipe Style needs to be assigned after a pipe has been created; the following styles can be assigned for the appropriate system using the drop down menu from the Pipe Properties.

Storm Water & Drainage

Pipe	▼
Information	A
Style	😪 Storm (Single Line)
Name	Pipe - (1)
Description	24 x 38 inch Concrete Elliptical Cul
Material	ByLayer
Show Tooltips	Yes
General	*
True Color	ByLayer
Layer	C-STRM-PIPE
Linetype	ByLayer

Sanitary Sewer

Pipe	-	
Information	▲	
Style	Sanitary (Single Line)	¢
Name	Pipe - (4)	
Description	🗐 8 inch PVC	_
Material	ByLayer	
Show Tooltips	Yes	
General	^	
True Color	ByLayer	
Layer	C-SSWR-PIPE	
Linetype	ByLayer	

Domestic Water

×	Pressure Pipe	- R R	
∎	Information	▲	Design
	Name	Pressure Pipe - (2)	De
	Description		
	Render Material	ByLayer	
	Style	🔗 Domestic Water (Centerline) 🗾 👻	
	Show Tooltips	No	
	General	*	Display
	True Color	 ByLayer 	Dis
	Layer	C-WATR-PIPE	
	Linetype	ByLayer	

Reclaimed Water

Pressure Pipe	- 💽 🕵 🞼	_
Information	▲	esign
Name	Pressure Pipe - (3)	De
Description		
 Render Material	ByLayer	
Style	🔗 Reclaimed Water (Centerline) 🗾 👻	
Show Tooltips	Yes	
General	*	Display
True Color	ByLayer	Dis
Layer	C-WATR-RCLM-PIPE	
Linetype	ByLayer	

Electrical

Ρ	ressure Pipe	- 💽 🕂 🕅	
In	nformation	•	Design
_	Name	Pressure Pipe - (4)	ŏ
	Description		
	Render Material	ByLayer	
	Style	Sectrical (Centerline)	
	Show Tooltips	Yes	
G	eneral	*	Display
	True Color	ByLayer	Dis
	Layer	E-PRIM-UGND-PIPE	
	Linetype	ByLayer	

Communications

F	Pressure Pipe		
I	nformation	•	
-	Name	Pressure Pipe - (5)	ć
	Description		
	Render Material	ByLayer	_
	Style	Communications (Centerline) 🗸	
	Show Tooltips	No	
0	Seneral		ż
	True Color	ByLayer	ż
	Layer	E-COMM-UGND-PIPE	
	Linetype	ByLayer	
			_ <u> </u>

Natural Gas



Jet Fuel

Pressure Pipe		
Information	^	
Name	Pressure Pipe - (7)]
Description		1
Render Material	ByLayer	1.
Style	🖉 Jet Fuel (Centerline) 🗾 👻	
Show Tooltips	No	
General	*	
True Color	ByLayer	
Layer	C-FUEL-MAIN-PIPE	1
Linetype	ByLayer	

Fire Water

Pressure Pipe	-]
Information	•	
Name	Pressure Pipe - (8)	(
Description		
Render Material	ByLayer	_
Style	🏑 Fire Water (Centerline) 🗸 🗸	
Show Tooltips	Yes	
General	×	:
True Color	ByLayer	
Layer	C-WATR-FIRE-PIPE	
Linetype	ByLayer	

GIS Attribute Data

LAWA records specific attribute data for utilities in the Airport Enterprise GIS database (AEGIS). Property Set Definitions are used in Civil 3D in order to collect the required data.

For additional information, and specific attributes required for your project, see the LAWA GIS Standards and contact the LAWA GIS department.

Autodesk Civil 3D Property Sets

To access Property Set Definitions in Civil 3D, type AECSTYLEMANAGER at the command line. Expand Documentation Objects and Property Set Definitions to reveal the LAWA_AEGIS Property Set. The LAWA_AEGIS Property Set can be added to lines, Polylines, Pipe, and Pressure Pipes as it is in the template. Additional categories can be added via the Applies to tab of the Style Manager. A sample set of metadata attribute fields have been prepopulated in the Property Set. You must confirm the required attributes fields and acceptable values with LAWA prior to deliverable submission.

Image: Section Content in the image in								
□ Documentation Objects □ A 2D Section/Elevation Styles □ A 2D Section/Elevation Styles □ Property Set Definitions □ LAWA_AEGIS □ A Multi-Purpose Objects □ A SENTITY SET NAME □ A SENTITY SET NAME □ AS ENTITY CLASS NAME AS ENTITY CLASS NAME □ AS ENTITY SET NAME □ AS ENTITY TYPE NAME □ AS ENTITY SET NAME □ AS CONTACT_DIFO □ AS CONTACTON_NAME □ AS CONTON_NAME								
□ Documentation Objects □ A2 D5 Section/Elevation Styles □ A12 Property Data Formats □ LAWA_AEGIS □ LASS ENTITY VPE NAME AS ENTITY VYE NAME □ LASS ENTITY VPE NAME AS ENTITY VYE NAME □ LASS CONTACT_INFO □ LASS CONTACTO_INAS CINCATION AS_DISCRIMINATOR_N_AS_INST_LOTTON □ L								
Hab Property Data Formats Property Set Definitions LAXA_AEGIS TAS_ENTITY CLASS NAME AS ENTITY CLASS NAME Te LASE ENTITY CLASS NAME AS ENTITY SET NAME AS ENTITY VER NAME AS ENTITY SET NAME Te LAS ENTITY VER NAME AS ENTITY TYPE NAME AS ENTITY VER NAME AS ENTITY TYPE NAME AS ENTITY OF NAME TE LAS CONTACT_INFO AS_CONTACT_INFO AS_CREATED_BY AS_CREATED_BY TE LAS_DISCRMINATOR AS_DISCRMINATOR AS_DISCRMINATION TRE AS_SOURCE_CITATION AS_SOURCE_TA								
Property Set Definitions Property Set Definitions As ENTITY CLASS NAME AS ENTITY CLASS NAME Te As ENTITY TYPE NAME AS ENTITY TYPE NAME AS ENTITY TYPE NAME TE AS CONTACT_INFO AS_CONTACT_INFO AS_CONTACT_INFO TE AS_CONTACT_INFO AS_CONTACT_INFO TE AS_CREATED_BY AS_CREATED_DATE AS_DISCRIMINATOR_VALUE TE AS_DISCRIMINATOR_VALUE TE AS_LOSTIDIN AS_DISCRIMINATOR_VALUE TE AS_LOSTIDIN AS_DISCRIMINATOR_VALUE TE AS_CONTACTION_INAME AS_LOSTIDIN AS_DISCRIMINATOR_VALUE TE AS_LOSTIDIN AS_LOSTIDIN AS_DISCRIMINATOR_VALUE TE AS_LOSTIDIN AS_LOSTIDIN AS_DISCRIMINATOR_VALUE TE AS_CONTACTION_INAME AS_LOSTIDIN AS_DISCRIMINATOR_VALUE TE AS_CONTACTION_INAME AS_LOSTIDIN AS_DISCRIMINATOR_VALUE TE AS_CONTED_BY AS_LOSTIDIN AS_DISCRIMINATOR_VALUE TE AS_CONTACTION_INAME AS_LOSTIDIN TE AS_CONTACTION_INAME AS_LOSTIDIN AS_DISCRIMINATOR_VALUE TE AS_CONTACTION_INAME AS_LOSTIDIN TE AS_CONTACTION_INAME AS_LOSTIDIN TE AS_CONTACTION_INAME AS_LOSTIDIN TE AS_CONTACTION_INAME TE AS_CONTACTION TE AS_CONTACTION_INAME TE AS_CONTACTION_INAME TE AS_CONTACTION_INAME TE AS_CONTACTION_INAME TE AS_CONTACTION	pe Sour	ce Default	Units	Format	Example	Visible	Order	Ξ.
Image: Second State Image: Second State<				Standard		~		
Image: Second State Image: Second State<	ext			Standard				4
□ AS ENTITY TYPE NAME AS ENTITY TYPE NAME Te □ AS_COMMENT AS_COMMENT Te □ AS_CONTACT_INFO AS_CONTACT_INFO Te □ AS_CONTACT_INFO AS_CONTACT_INFO Te □ AS_CREATED_DATE AS_CONTACT_INFO Te □ AS_DISCRIMINATOR AS_DISCRIMINATOR AS_DISCRIMINATOR □ AS_CAS_CONTACT_INFO Te Te □ AS_DISCRIMINATOR AS_DISCRIMINATOR AS_DISCRIMINATOR □ AS_CLAST_EDITED_BY AS_LAST_EDITED_BY Te □ AS_CLAST_EDITED_BY AS_LOSTION_NAME Te □ AS_ONNER_OPERATOR AS_UOULTO_NAME Te □ AS_QUALITY_LEVEL AS_QUALITY_LEVEL Te □ AS_QUALITY_LEVEL AS_QUALITY_LEVEL Te □ AS_SON_CODE AS_ERASON_CODE Te □ AS_SON_CODE AS_SON_CODE Te □ AS_SON_CODE AS_SON_CODE Te □ AS_SON_CODE AS_SON_CODE Te □	ext			Standard		 Image: A start of the start of		f_x
Image: Section of the section of th	ext			Standard		1		
U+AS_CREATED_BY AS_CREATED_DATE AS_CREATED_DATE U+AS_CREATED_DATE AS_DATE_LAST_EDITED TE U+AS_DIST_SATURD AS_DATE_LAST_EDITED TE U+AS_DIST_SATURD AS_DISTON AS_DISTONION TE U+AS_DISTON AS_DISTONION AS_DISTON AS_DISTON TE U+AS_DISTON AS_DISTON AS_DISTON TE U+AS_CLAST_EDITED BY TE TE U+AS_LAST_EDITED_BY AS_LAST_EDITED_BY TE U+AS_OWNER_OPERATOR AS_OWNER_OPERATOR TE U+AS_QUALITY_LEVEL AS_QUALITY_LEVEL TE U+AS_QUALITY_LEVEL AS_QUALITY_LEVEL TE U+AS_SON_CODE AS_REASON_CODE TE U+AS_SON_CODE AS_SON_CODE TE U+AS_SON_CODE AS_CON_CODE TE U+AS_SON_CODE AS_SON_CODE	ext			Standard		 Image: A start of the start of		18E
Um, AS_CREATED_BY AS_CREATED_DATE AS_CREATED_DATE Um, AS_CREATED_DATE AS_CREATED_DATE TE Um, AS_DATE_LAST_EDITED AS_DATE_LAST_EDITED TE Um, AS_DISPOSITION AS_DISFOSITION AS_DISFOSITION Um, AS_DISFOSITION AS_DISFOSITION AS_DISFOSITION Um, AS_CLAST_EDITED_BY AS_GIS_LAYER TE Um, AS_LAST_EDITED_BY AS_LAST_EDITED_BY TE Um, AS_COLATION_NAME AS_LOCATION_NAME TE Um, AS_OWNER_OPERATOR AS_OWNER_OPERATOR TE Um, AS_QUALITY_LEVEL AS_QUALITY_LEVEL TE Um, AS_REASON_LOODE AS_REASON_CODE TE Um, AS_SONT, CODE AS_REASON_CODE TE Um, AS_SONT, ASUME DATLINK TE Um, AS_SONT, TABLE_NAME AS_SONT, CODE TE Um, AS_SONT, ASUME DATLINK TE Um, AS_SONT, AND DATLINK TE Um, AS_SONT, D DISPOSTIN_D TE Um, AS_DATLUANLITY DATLINK TE Um, AST_UM DATLINK TE TE UMATLAUR DATLINK TE	ext			Standard		1		8
Image: Section of the section of th	ext			Standard		 Image: A second s		
Image: Section 2.1 Image: Section 2.1 Image: Section 2.1 Image: Section 2.1 Image: Section 2.1 Image: Section 2.1 Image: Section 2.1 Image: Section 2.1 Image: Section 2.1 Image: Section 2.1 Image	ext			Standard		1		E
III. + AS_DISCRIMINATOR AS_DISCRIMINATOR AS_DISPOSITION Te III. + AS_DISPOSITION AS_DISPOSITION AS_DISPOSITION Te III. + AS_GIS_LAVER AS_GIS_LAVER Te III. + AS_LAST_EDITED_BY AS_LAST_EDITED_BY Te III. + AS_LOCATION_NAME AS_LOCATION_NAME Te III. + AS_OWNER_OPERATOR AS_OWNER_OPERATOR Te III. + AS_QUALITY_LEVEL AS_PUBLISHED AS_PUBLISHED Te III. + AS_QUALITY_LEVEL AS_QUALITY_LEVEL Te III. + AS_SOURCE_CITATION AS_SOURCE_CITATION Te III. + AS_SOURCE_CITATION AS_OURCELITATION Te III. + AS_OURCE_CITATION AS_OURCE_CITATION Te III. + AS_DOURCE_INSTALLED DATE_INSTALLED TE III. + DATE_INSTALLED DATE_INSTALLED <td< td=""><td>ext</td><td></td><td></td><td>Standard</td><td></td><td> Image: A start of the start of</td><td></td><td></td></td<>	ext			Standard		 Image: A start of the start of		
U+ AS_DISPOSITION AS_DISPOSITION Te U+ AS_GIS_LAYER AS_GIS_LAYER Te U+ AS_LAST_EDITED_BY AS_LAST_EDITED_BY Te U+ AS_LOCATION_NAME AS_LOCATION_NAME Te U+ AS_UNVER_OPENATOR AS_UNVER_OPENATOR Te U+ AS_OWNER_OPENATOR AS_UNVER_OPENATOR Te U+ AS_OWNER_OPENATOR AS_OWNER_OPENATOR Te U+ AS_OUNTLY_LEVEL AS_QUALITY_LEVEL Te U+ AS_SDS_TABLE_NAME AS_SOURCE_CITATION Te U+ AS_SOURCE_CITATION AS_SOURCE_CITATION Te U+ AS_SOURCE_CITATION AS_SOURCE_CITATION Te U+ AS_SOURCE_CITATION AS_SOURCE_CITATION Te U+ AS_SOURCE_CITATION AS_SOURCE_CITATION Te U+ AS_CORD DATLINK TE U+ ASTALUE DATLINK Te U+ ASTALUE DATE_MATLIED Te U+ ASTATUS DISPOSTN_D Te U+ ARRATIVE NARATIVE TE U+ ARRATIVE STATUS Te				Standard				<i>1</i>
Image: Ass_GIS_LAYER Ass_GIS_LAYER Te Image: Ass_LAST_EDITED_BY Ass_LAST_EDITED_BY Te Image: Ass_LOCATION_NAME Ass_LOCATION_NAME Ass_LOCATION_NAME Image: Ass_OWNER_OPERATOR Ass_OWNER_OPERATOR Te Image: Ass_OWLENER_OPERATOR Ass_OWLENEO Te Image: Ass_OWLENER_OPERATOR Ass_OWLENED Te Image: Ass_OWLENER_OPERATOR Ass_OWLENER_OPERATOR Te Image: Ass_SOURCE_CITATION Ass_SOURCE_CITATION Te Image: Ass_SOURCE_CITATION Ass_SOURCE_CITATION Te Image: Ass_ONTALINK DATE_ACQRD DATE_ACQRD Te Image: Assource_CITATIONALITY DISECTIONALITY DE Te Ima				Standard		 Image: A start of the start of		L
III.+AS_LAST_EDITED_BY AS_LAST_EDITED_BY TE III.+AS_LOCATION_NAME AS_LOCATION_NAME TE III.+AS_DWNER_OPERATOR AS_OWNER_OPERATOR TE III.+AS_PUBLISHED AS_PUBLISHED TE III.+AS_QA_STATUS AS_QA_STATUS TE III.+AS_QA_STATUS AS_QA_STATUS TE III.+AS_QA_STATUS AS_QA_STATUS TE III.+AS_SOUNCDE AS_REASON_CODE TE III.+AS_SOURCE_CITATION AS_SOURCE_CITATION TE III.+AS_DATALINK DATE_INSTALLED TE III.+ASTALLED DATE_INSTALLED TE III.+ASTALLP MAT_D TE III.+ART_D MAT_D TE III.+ART_D MAT_D TE III.+ARTIVE STATUS TE	ext			Standard		 Image: A second s		
U+AS_LOCATION_NAME AS_LOCATION_NAME Te U+AS_OWNER_OPENATOR AS_OWNER_OPENATOR Te U+AS_PUBLISHED AS_PUBLISHED Te U+AS_QA_STATUS AS_QA_STATUS Te U+AS_QA_STATUS AS_QA_STATUS Te U+AS_QA_STATUS AS_QA_STATUS Te U+AS_QA_STATUS AS_QA_STATUS Te U+AS_SARASON_CODE AS_REASON_CODE Te U+AS_SDS_TABLE_NAME AS_SOURCE_CITATION Te U+AS_SOURCE_CITATION AS_SOURCE_CITATION Te U+AS_SOURCE_CITATION AS_SOURCE_CITATION Te U+AS_ONTALINK NATALINK Te U+AS_DORECTIONALITY DRECTIONALITY Te U+DISPOSTN_D DISPOSTN_D Te U+ARRATIVE NARATIVE NARATIVE Te				Standard				6-0
U+AS_OWNER_OPERATOR AS_OWNER_OPERATOR Te U+AS_PUBLISHED AS_VALTUS AS_QA_STATUS Te U+AS_QA_STATUS AS_QA_STATUS Te U+AS_QUALITY_LEVEL AS_QUALITY_LEVEL Te U+AS_SOS_TABLE_NAME AS_SOS_TABLE_NAME Te U+AS_SOS_TABLE_NAME AS_SOURCE_CITATION Te U+AS_SOURCE_CITATION AS_SOURCE_CITATION Te U+AS_NORCE_CITATION AS_SOURCE_CITATION Te U+AS_NORCE_CITATION AS_SOURCE_CITATION Te U+AS_NORCE_CITATION AS_SOURCE_CITATION Te U+AS_NORCE_CITATION AS_SOURCE_CITATION Te U+ASTALINK DATE_INSTALLED Te U+ONTE_ACORD DATE_ACORD Te U+ONTE_ACORD DATE_ACORD Te U+ONTE_ACORD DATE_INSTALLED TE U+ONTE_ACORD DATE_INSTALLED TE U+ONTE_ACORD DATE_ACORD TE U+ONTE_ACORD DATE_INSTALLED TE U+ONTE_ACORD DISPOSTN_D TE U+ONTE_ACORD MAT_D TE U+ONTE_ACORD				Standard		 Image: A start of the start of		
■. AS_PUBLISHED AS_PUBLISHED Te ■. AS_QA_STATUS AS_QA_STATUS Te ■. AS_QUA_STATUS AS_QUALITY_LEVEL Te ■. AS_QUALITY_LEVEL AS_QUALITY_LEVEL Te ■. AS_SOS_TABLE_NAME AS_SOS_TABLE_NAME Te ■. AS_SOS_TABLE_NAME AS_SOURCE_CITATION Te ■. AS_SOURCE_CITATION AS_SOURCE_CITATION Te ■. ADATE_ACQRD DATE_ACQRD Te ■. ADATE_INSTALLED DATE_INSTALLED Te ■. ADATE_INSTALLED DATE_INSTALLED Te ■. ADATE_DISFON_D DISPOSTN_D Te ■. ADAT_D MAT_D Te ■. ADATE_DISTALLY NARATIVE NARATIVE				Standard				
U+AS_QA_STATUS AS_QA_STATUS Te U+AS_QUALITY_LEVEL AS_QUALITY_LEVEL Te U+AS_STAD_CODE AS_REASON_CODE Te U+AS_SDS_TABLE_NAME AS_SDS_TABLE_NAME Te U+AS_SOURCE_CITATION AS_SOURCE_CITATION Te U+ASTE_NSTALLED DATE_MSTALLED Te U+ASTE_NSTALLED DATE_MSTALLED Te U+ASTE_NSTALLED DISPOSTN_D Te U+ASTATUS STATUS Te				Standard		<u> </u>		
□+ AS_QUALITY_LEVEL AS_QUALITY_LEVEL Te □+ AS_REASON_CODE AS_REASON_CODE Te □+ AS_SSDS_TABLE_NAME AS_SOS_TABLE_NAME Te □+ AS_SOURCE_CITATION AS_SOURCE_CITATION Te □+ AS_AS_CORCE_CITATION AS_SOURCE_CITATION Te □+ DATALINK DATE_ACQRD DATE_ACQRD Te □+ DATE_ACQRD DATE_INSTALLED Te □+ DISPOSTN_D DISPOSTN_D Te □+ MAT_D MAT_D Te □+ NARRATIVE NARRATIVE Te				Standard		 Image: A start of the start of		
□+ AS_REASON_CODE AS_REASON_CODE Te □+ AS_SOS_TABLE_NAME AS_SOS_TABLE_NAME Te □+ AS_SOURCE_CITATION AS_SOURCE_CITATION Te □+ OATALINK DATALINK Te □+ OATALINK DATE_ACQRD TE □+ OATE_INSTALLED DATE_INSTALLED Te □+ OISFONALITY DIRECTIONALITY Te □+ DISFOSTN_D DISPOSTN_D Te □+ MAT_D MAT_D Te □+ NARRATIVE NARRATIVE Te				Standard		 Image: A start of the start of		
U+AS_SDS_TABLE_NAME AS_SDS_TABLE_NAME Te U+AS_SOURCE_CITATION AS_SOURCE_CITATION Te U+AS_SOURCE_CITATION AS_SOURCE_CITATION Te U+AS_SOURCE_CITATION AS_SOURCE_CITATION Te U+AS_SOURCE_CITATION AS_SOURCE_CITATION Te U+AS_SOURCE_CITATION DATLINK Te U+AS_SOURCE_INSTALLED DATE_INSTALLED Te U+ASTE_INSTALLED DISPOSTN_D Te U+ASTE_D DATE_DISTALLED Te U+ASTE_D MAT_D Te U+ARRATIVE NARCATIVE Te U+ARRATIVE STATUS STATUS Te				Standard		 Image: A start of the start of		
□				Standard		 Image: A state of the state of		
Image: bold and a constraints DATALINK DATALINK Te Image: bold and and and and and and and and and an				Standard		 Image: A start of the start of		
■+ DATE_ACQRD DATE_ACQRD Te ■+ DATE_INSTALLED DATE_INSTALLED Te ■+ DATE_INSTALLED DATE_INSTALLED Te ■+ DISPOSTN_D DISPOSTN_D Te ■+ DISPOSTN_D DISPOSTN_D Te ■+ MAT_D MAT_D Te ■+ NARRATIVE NARRATIVE Te ■+ STATUS STATUS Te				Standard		 Image: A start of the start of		
□+DATE_INSTALLED DATE_INSTALLED Te □+DIRECTIONALITY DIRECTIONALITY Te □+DISPOSTN_D DISPOSTN_D Te □+MAT_D MAT_D Te □+NARRATIVE NARRATIVE Te □+STATUS STATUS Te				Standard		 Image: A second s		
□_+ DIRECTIONALITY DIRECTIONALITY Te □_+ DISPOSTN_D DISPOSTN_D Te □_+ MAT_D MAT_D Te □_+ NARRATIVE NARRATIVE Te □_+ STATUS STATUS Te				Standard		 Image: A second s		
□_+ DISPOSTN_D DISPOSTN_D Te □_+ MAT_D MAT_D Te □_+ NARRATIVE NARRATIVE Te □_+ STATUS STATUS Te				Standard		 Image: A state of the state of		
□				Standard				
□_+NARRATIVE NARRATIVE Te □_+STATUS STATUS Te				Standard		 Image: A state of the state of		
Te STATUS STATUS Te				Standard				
				Standard		- -		
				Standard		 Image: A state of the state of		
□+USER_FLAG USER_FLAG Te				Standard				
Te USERFLAG USERFLAG TE				Standard		 Image: A state of the state of		
				Standard				
			OK	Cano		Apply		Help

Use the tools on the right to create or delete Property Set Definitions based on the specific project requirements.

To add Property Set Definitions to objects in Civil 3D, first select the object or objects, then select the Extended Data tab of the properties palette and the Add Property Sets button at the bottom.

×				
-][Top][2D ₩ ਛ	Pipe	 ▼ ● ●		
	DOCUMENTATION	•	Design	
	- ijperinik		Des	
		(0)		
	Reference documents	- (0)	_	
			olay	
			Display	
Add P	roperty Sets	X		
	LA <u>5</u>		_	
	WA_AEGIS	Select All	ata	
		Clear All	Extended Data	
			ende	
			EXt	
			s	
			Object Class	
	OK Cancel	Help	ject	
			g	
erties				
Y do	\frown			
I				
×		🛛 🗙 🔍 🖂 - Тур		command
	la da Lavautt (Lavaut)	тур	e u	communu

Select the LAWA_AEGIS Property Set to add the property Set definitions to the selected object(s). Once the Property Sets is added, the Property Set Definitions are visible on the Extended Data tab of the Properties Palette. Values can be manually input in this dialog. Acceptable input values must be confirmed with LAWA prior to deliverable submission.

	Pipe	 ▼ ● ●	
	DOCUMENTATION	•	j.
	пурсник		Decion
	Notes		
	Referench documents		
F	PROPERTY SETS	*	
L	AWA_AEGIS	•	
	ALTERNATIVE		
	AS ENTITY CLASS NA		Dicular
	AS ENTITY SET NAME		
	AS ENTITY TYPE NAME		
	AS_COMMENT		
L	AS_CONTACT_INFO		f
	AS_CREATED_BY		Evtended Data
	AS_CREATED_DATE		
	AS_DATE_LAST_EDITED		ten
	AS_DISCRIMINATOR_V		ú
	AS_DISPOSITION		
	AS_GIS_LAYER		
	AS_LAST_EDITED_BY		
1	AS_LOCATION_NAME		t
	AS_OWNER_OPERATOR		Ohiart Clace
	AS_PUBLISHED		
	AS_QA_STATUS		
	AS_QUALITY_LEVEL		
	AS_REASON_CODE		
	AS_SDS_TABLE_NAME		
	AS_SOURCE_CITATION		

Sample Civil 3D views

The following are examples of how Pipe Networks appear in Civil 3D both Plan and 3D views.

NOTE: Civil 3D Pipe Network Styles, and any line types associated with those styles are not compatible with LAWA's GIS Database (AEGIS).

Pipe Networks in Plan View



Pipe Networks in 3D View



Finished Civil 3D Model

