Los Angeles Noise Mitigation



Captain Dan L. Delane FedEx Express Fleet Check Airman 13 November 2013

FedEx Express

-FedEx Is committed to reducing NOISE and carbon footprint for both air and ground operations.



How does FedEx Express Mitigate Noise in L.A.?

- All flight operations procedures for ground ops, takeoff, departure, arrival and taxi-in are tailored to minimize noise while reducing emissions.
- Pilots going through initial training, recurrent training and checking events are briefed and evaluated on compliance with noise-reduction initiatives and procedures. Compliance is mandatory.

Modern Aircraft

 Older aircraft, such as the Boeing 727 have been phased out; the complete fleet is now ICAO Stage 3 or the more stringent Stage 4 Noise compliant aircraft, like this brand-new B-777. All our new aircraft are twin-engine, B-757, B-767, B-777.



Newer Aircraft

Twin engine fuel thriftiness, less noise and less carbon footprint for the same payload of some of our older (1992 generation) aircraft. Our brand-new B-777 and B-767 freighters have some of the most advanced and fuel efficient engines on the market today.

 As our older MD-10 freighters (three engine ICAO Stage 3 noise compliant) are phased out, they are replaced with brand-new B-767 freighters. These MD-10's currently are in use daily here in Los Angeles.



Ground/Taxi Noise-Reduction Initiatives

 Each of our aircraft here in Los Angeles, at every gate, is attached to electrical ground power rather than using the onboard APU (auxiliary power unit) until the power must be removed to push back the aircraft for engine start. No noise.



Ground Power





Start and Taxi-out...

- As the aircraft is pushed out, our procedure is to start only one engine on twin-engine aircraft, two on three engine aircraft, always the engine AWAY from the south side. This cuts the noise significantly.
- The remaining engine(s) started just prior to taking the runway for departure, usually three minutes.





Taxi to the Runway



Runway selection?



Runway selection

- All pilots procedurally are required to request the inboard runways, away from residential areas, for takeoff. Runway 25R or 24L, if eastbound, 07L, 06R. This puts the noise footprint farther away so as to be less intrusive. Why do we see aircraft still departing runway 25L?
- Takeoff flaps are *procedurally* selected **minimum** for less thrust required, less noise, less carbon footprint.



	al - Home > Notams > KLAX - Windows Internet Explorer	
	ps://corp.pilot.fedex.com/weather/notam/view?icao=klax&type=Operational	م
2	Favorites Tools Help	
	🖕 🙋 Playback Messages 🔌 Delta Air Lines - Airline Ti 📑 FedEx Corporate 🙋 Suggested Sites 🔻 🙋 Get more Add-ons 👻	
FedEx Weather Po	rtal - Home > Notams > KLAX 👘 🔻 🖾 👘 👻 Page 🔻	Safety ▼ Tools ▼ 🔞 ▼
	Flight Operations Home Site Map Change Password Logout Daniel Delane	
	Local Weather: City, ST or Zip or ICAO Weather INformation Display System Home -> Notams -> KLAX	
	Weather Surface Maps Aviation Tools Help Login	
	Location: klax Type: Operational Search NOTAMs for KLAX Subscribe to this NOTAM feed:	
	LOS ANGELES INTL	
	LIDO Chart NOTAMs	
	ID: KLAX 09 Sep 00:00 2013 Last Modification LIDO Chart NOTAMs have been retired	
	To request Jeppesen Chart Change Notices for any airport or FIR use http://www.jetplan.com/weather/html/text/CCNAdHocForm.shtml	
	Domestic NOTAMs	
	ID: 11/090 11 Nov 19:19 2013 Last Modification ILAX 11/090 LAX RWY 7R/25L CLSD DAILY 0700-1500 1311120700-1311151500	
	ID: 05/112 16 May 16:22 2013 Last Modification ILAX 05/112 LAX RWY 25R PAPI 0TS WEF 1305161621 ID: 05/111 16 May 16:18 2013 Last Modification	•1
	ILAX 05/111 LAX RWY 25L PAPI OTS WEF 1305161618 ID: 09/043 13 Sep 22:21 2011 Last Modification	•
	!LAX 09/043 LAX RWY 24L AT TWY E8 TORA 9900 ID: 11/092 12 Nov 19:52 2013 Last Modification !LAX 11/092 LAX TWY R BTN TWY D CLSD DAILY 0800-1400 1311130800-1311151400	
	ID: 11/086 10 Nov 04:30 2013 Last Modification ILAX 11/086 LAX TWY F BTN APCH END RWY 25L AND TWY A CLSD 1311121700-1311122100	
	ID: 11/087 10 Nov 04:30 2013 Last Modification !LAX 11/087 LAX TWY T BTN RWY 7R/25L AND TWY A CLSD 1311122100-1311122359 ID: 10/189 24 Oct 17:39 2013 Last Modification	
	ILAX 10/189 LAX TWY R NOT STD TAXI BTN TWY C AND CHECKPOINT 2 1310241727-1312201400EST	•
	!LAX 10/060 LAX TWY R BTN TWY D AND TWY C WORK IN PROGRESS CONST ADJ EAST EDGE 1310081934-1312201300	
	ID: 07/092 20 Jul 23:32 2012 Last Modification !LAX 07/092 LAX TWY E17 SOUTHBOUND TURNS FROM GATE 208 PROHIBITED	
	Internet Protected Mode: Off	🖓 🔻 🍕 100% 🔹

Departure Routing

 All departures are run strictly by the established RNAV or charted/published departures. No early turns unless directed by ATC. Pilots must adhere carefully to heading assignments or SID when heading west and turning south.



Climb-out Procedures

- Departing over water, initially westbound, Noise Abatement Departure Procedure (NADP) number 2 is used- clean up gear and flaps at 1000 feet, accelerate *away* from land rapidly, then climb to meet the restrictions on the RNAV charted departures.
- A new initiative we are using for departures from the east-facing runway, use NADP-1, which is Climb first rapidly to 3000 feet for less surface noise, then clean up. Less intrusive during early hours.

Arrival Procedures

- All arrivals are via a charted RNAV procedure or via radar vectors to a precision approach. FedEx is proactive in mandating Constant Descent Angle (CDA) arrivals and final descents- this procedure assures the minimum thrust required will be used at all times and the minimum landing flaps used to reduce the noise footprint to the minimum possible.
- Final landing flap selection and gear down are done as late on the approach as is safe to reduce the noise footprint farther out to the absolute minimum.
- CDA arrivals are the norm in Europe and some of Asia, eventually the United States will mirror and CDA arrivals will be the norm here.

Landing

- Early morning hours (normally 6 A.M.) the landing runway assigned will be towards the east, 07L or R, 06 L or R, depending on NOTAM closures and atmospherics.
- Our new initiative to reduce noise is to mandate IDLE REVERSE THRUST on landing, safety permitting. This significantly cuts the DB for adjoining neighborhoods.
- The APU will not be started after landing (noise) and our mandate is less-than-all-engine-taxi, shutting an engine down <u>immediately</u> after clearing the runway.

Other Noise Cutting Measures?

- FedEx maintains a heavy aircraft maintenance facility on the west end of the airport right between the runways. The Managing Director of Maintenance has implemented a curfew on engine runs, not to be done between 10:30 P.M. and 6:30 A.M.
- Questions?

